



KES ENERGY AUTOMATIC TRANSFER SWITCHES BY AMPHERE

The Kes Energy Automatic Transfer Switch, or ATS, ensures that you always have power to your systems in the event of an outage.



The ATS can detect mains (utility) power failure immediately and transfer power from the generator to the load in a seamless transition. Furthermore, once the mains power has been restored, the ATS will then switch back, sending the power from the mains to the load while also sending a shutdown command to the generator.




ATS



KES ENERGY MODEL	CHARGING	FREQ.	DISPLAY	AMPS	WEIGHT AND DIMENSIONS			Controller	
	Battery charger	Hz.	Type	Amps	Length mm	Width mm	Height mm	Weight Kg	Standard
									
KESATS40	5A	50/60	LCD	40	600	250	600	100	DSE 333
KESATS63	5A	50/60	LCD	63	600	250	600	100	DSE 333
KESATS80	5A	50/60	LCD	80	600	250	600	120	DSE 333
KESATS100	5A	50/60	LCD	100	600	250	600	120	DSE 333
KESATS160	5A	50/60	LCD	160	800	250	600	140	DSE 333
KESATS250	5A	50/60	LCD	250	800	250	600	180	DSE 333
KESATS400	5A	50/60	LCD	400	800	500	600	180	DSE 333
KESATS630	5A	50/60	LCD	630	800	600	1400	190	DSE 333
KESATS800	5A	50/60	LCD	800	800	600	1400	200	DSE 333
KESATS1000	5A	50/60	LCD	1000	800	600	1400	210	DSE 333
KESATS1250	5A	50/60	LCD	1250	800	600	1400	220	DSE 333
KESATS1600	5A	50/60	LCD	1600	900	800	1700	240	DSE 333
KESATS2500	5A	50/60	LCD	2500	900	800	1700	250	DSE 333





Typical Configuration



KES ENERGY AUTOMATIC TRANSFER SWITCHES



For more information, to request a technical specifications data sheet, or for tailor-made solutions, please contact KES ENERGY:

HEADQUARTERS (Italy) info@kes-energy.it

Dubai Office: infodubai@kes-energy.it

Spain Office: infospain@kes-energy.it